



**Lomanco® Omni Solar Vent™ (OSV-40)**

# **Extension Wire Installation Instructions**

## **Working from the inside of your attic or air space:**

1. Connect to solar panel wires. Connect the male end of the extension wires to the female ends of the solar panel wires. Connect the red extension wire to the red solar panel wire and the black extension wire to the black solar panel wire.
2. Connect to the motor wires. Connect the female end of the extension wires to the male ends of the motor wires. Connect the red extension wire to the red motor wire and the black extension wire to the black motor wire. **WARNING:** The unit will begin operation once the connection is made.



**1.800.643.5596 • Lomanco, Inc. • www.lomanco.com**